


SHIMANO

CURADO

S A-RB

CU-300EJ



(1RH399300U)

Please note that the number of adjusting washers may not be the same as shown in the exploded views. (Adjustment will vary with each individual product.)

Part No.	Description	Part No.	Description	Part No.	Description
BNT0011	Screw	BNT2717	E Lock	BNT3906	Handle Retainer
BNT0015	Drag Spring Washer	BNT2801	Yoke	BNT3910	Roller Clutch Bearing
BNT0032	Bearing Retainer	BNT3041	Clutch Plate Shaft Support	BNT3985	Star Drag
BNT0042	Line Guide Pawl	BNT3045	Worm Bushing B	BNT3986	Screw
BNT0060	Spacer	BNT3054	Click Pin Retainer	BNT3987	Screw
BNT0194	Ball Bearing	BNT3055	Click Spring	BNT3988	Screw
BNT0623	Screw	BNT3056	Click Pin	BNT3989	Cast Control Cap
BNT0664	Spacer B	BNT3208	Star Drag Click Plate	BNT3991	Thumb Rest
BNT0686	E Lock	BNT3483	Anti-Reverse Ratchet	BNT3992	Line Guide
BNT0817	Screw	BNT3490	Idle Gear	BNT3993	One-Piece Frame
BNT0987	Screw	BNT3595	Pawl Cap	BNT3994	Spool Assembly
BNT1106	Star Drag Spring	BNT3596	Roller Clutch Inner Tube	BNT3995	Left Side Plate
BNT1289	Star Drag Spacer	BNT3610	Brake Case Spacer	BNT3996	Turnkey Dial
BNT1419	Yoke Spring	BNT3621	Ball Bearing	BNT4116	Screw
BNT1465	Clutch Pawl Spring	BNT3687	Handle Nut	BNT4185	Handle Knob Seal
BNT1473	Screw	BNT3692	Key Washer	BNT4186	Washer
BNT1499	Screw	BNT3695	Drive Shaft	BNT4187	Ball Bearing
BNT1636	Screw	BNT3696	Idle Gear	BNT4188	Handle Knob
BNT1671	Washer	BNT3698	Worm Shaft	BNT4189	Handle Knob Shaft Seal
BNT1672	E Lock	BNT3699	Worm Bushing A	BNT4190	Handle Shank Assembly
BNT1696	Cast Control Spacer	BNT3700	Line Guard	BNT4191	Handle Assembly
BNT1715	Brake Collar (red)	BNT3701	Level Wind Guide	BNT4192	Right Side Plate
BNT2119	Screw	BNT3703	Clutch Pawl	BNT4193	Drive Gear
BNT2122	Click Pin	BNT3704	Clutch Plate	BNT4194	Ball Bearing
BNT2123	Click Spring	BNT3705	Anti-Reverse Pawl	BNT4195	Pinion Gear
BNT2143	Ball Bearing	BNT3707	Clutch Bar Guide B	BNT4196	Drag Washer
BNT2144	Washer	BNT3708	Quick-Fire II Clutch Bar	BNT4197	Drag Washer
BNT2165	Clutch Cam Retainer	BNT3709	Level Wind Guard		
BNT2224	Spool Tension Spacer	BNT3711	Brake Case		
BNT2406	Clutch Cam	BNT3722	Star Drag Nut		
BNT2429	O Ring	BNT3740	Stabilizer Bar	BNT1713	Brake Collar (green) (accessory)
BNT2437	Drive Shaft Retainer	BNT3763	Side Plate Spring	BNT3237	Wrench (accessory)

(220518)