



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	6W4000010	Drag Knob	31	6W4029010	Pinion Gear
2	6W4001010	Drag Coil Spring	32	6W4030010	Handle Assembly
3	6W4002010	Drag Metal	33	6W4031010	Screw (F)
4	6W4003010	Washer (A)	34	6W4032010	Anti-Reverse Lever
5-9	6W4004010	Spool Assembly	35	6W4033010	Plate (A)
6	6W4005010	Click Pawl	36	6W4034010	Body
7	6W4006010	Click Spring	37	6W4035010	Screw (G)
8	6W4007010	Washer (B)	38	6W4036010	Anti-Reverse Pawl
9	6W4008010	Screw (A)	39	6W4037010	Anti-Reverse Pawl Spring
10	6W4009010	Washer (C)	40	6W4038010	Anti-Reverse Cam Spring
11	6W4010010	Main Shaft	41	6W4039010	Anti-Reverse Cam
12	6W4011010	Bail Assembly	42	6W4040510	Bushing (B)
13	6W4012010	Rotor Nut	43	6W4041010	Washer (E)
14	6W4013010	Screw (B)	44	6W4042010	Drive Gear
15	6W4014010	Screw (C)	45	6W4043010	Oscillating Slider
16	6W4015010	Washer (D)	46	6W4044010	Oscillating Slider Pin
17	6W4016010	Line Roller	47	6W4045010	Screw (H)
18	6W4017010	Line Roller Pin	48	6W4046010	Side Cover
19	6W4018010	Line Roller Collar	49	6W4047010	Plate (B)
20	6W4019010	Screw (D)	50	6W4048010	Screw (I)
21	6W4020010	Cover (A)	51	6W4049010	Screw (J)
22	6W4021010	Bail Trip Lever			
23	6W4022010	Bail Trip Lever Spring			
24	6W4023010	Rotor			
25	6W4024010	Screw (E)			
26	6W4025010	Bearing Retainer			
27	6W4026010	Ball Bearing			
28	6W4027010	Collar (A)			
29	6W4028010	Spacing Sleeve			
30	6W4026510	Bushing (A)			

DF 100AM SPECIAL PARTS		
Key No.	Parts No.	Parts Name
12	6W4011020	Bail Assembly
52	6W4050010	Cover (B)