


# Models LX - 4.1 Parts List



1 - Main Housing	LX401-001	16 - Brake Disk	LX401-016	31 - Drive Shaft	LX401-031	46 - Preset Knob	LX401-046	61 - Rod Mount Studs (2 req.)	LX401-061
2 - Spool Shaft	LX401-002	17 - Pinion Gear	LX401-017	32 - Drive Shaft Bearing (2 req.)	LX401-032	47 - Crank Arm	LX401-047	62 - Rod Mount Clamp	LX401-062
3 - Belleville Washers (4 req.)	LX401-003	18 - Pinion Bearing	LX401-018	33 - End Housing Screw (3 req.)	LX401-033	48 - Crank Arm Washer	LX401-048	63 - Rod Mount Nut (2 req.)	LX401-063
4 - Pusher Bushing	LX401-004	19 - End Housing	LX401-019	34 - Stop Pin (2 req.)	LX401-034	49 - Acorn Nut	LX401-049	64 - Pin Support	LX401-064
5 - Spool Bearing	LX401-005	20 - Screw (4 req.)	LX401-020	35 - Stop Pin Screw (2 req.)	LX401-035	50 - Locking Plate	LX401-050	65 - Clicker Pin	LX401-065
6 - Spool Tube	LX401-006	21 - Cover Plate	LX401-021	36 - Drive Shaft Tube	LX401-036	51 - Handle Stem Washer	LX401-051	66 - C Spring Screw	LX401-066
7 - Clicker Gear Retainer Ring	LX401-007	22 - Stright Stop Spring (2 req.)	LX401-022	37 - Crank Arm Spacer	LX401-037	52 - Handle Tube washer (2 req.)	LX401-052	67 - C Spring	LX401-067
8 - Clicker Gear	LX401-008	23 - Stright Stop	LX401-023	38 - Lever Bushing	LX401-038	53 - Handle Tube	LX401-053	68 - Pin Washer	LX401-068
9 - Spool	LX401-009	24 - Untireverse Dog	LX401-024	39 - Lever Arm	LX401-039	54 - Lock Screw Nut	LX401-054	69 - Clicker Arm	LX401-069
10 - Brake Pad	LX401-010	25 - Dog Spring	LX401-025	40 - Lever Knob	LX401-040	55 - Handle Shoulder Bolt	LX401-055	70 - Pin E-Clip	LX401-070
11 - Brake Pad Retainer Ring	LX401-011	26 - Cover Plate Screw (2 req.)	LX401-026	41 - Knob Screw	LX401-041	56 - Lock Screw Washer	LX401-056		
12 - Spool Bearing	LX401-012	27 - Dog Cover Plate	LX401-027	42 - Female Cam	LX401-042	57 - Lock Screw	LX401-057		
13 - Spool Spring Washer (2 req.)	LX401-013	28 - Shaft Lock Nut	LX401-028	43 - Male Cam	LX401-043	58 - Handle Knob	LX401-058		
14 - Sool Spring	LX401-014	29 - Shaft Nut Washer	LX401-029	44 - O-Ring	LX401-044	59 - Rod Mount	LX401-059		
15 - Brake Bearing	LX401-015	30 - Drive Gear	LX401-030	45 - Preset Knob Spring	LX401-045	60 - Rod Mount Screw (4 req.)	LX401-060		