




* Mark indicates the interchangeable parts for right and left handed reels.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
01	2210-01	Spool Assembly	40	2210-40	Bearing Retainer
1	2210-1	Drag Adjusting Nut Assembly	40	2210LH-40	Bearing Retainer
2	2210-2	Clutch Retaining Spring	41	2210-41	Ball Bearing
3	2210-3	Drag Keyed Washer	42	2210-42	Pinion
4	2210-4	Drag Washer	42	2210LH-42	Pinion
5	2210-5	Drag Eared Washer	43	2210-43	Frame Assembly
7	2210-7	Click Pawl	43	2210LH-43	Frame Assembly
8	2210-8	Click Pawl Screw	44	2210-44	Cover Screw, Opposite Crank
9	2210-9	Drag Washer, rear	45	2210-45	Cover Assembly, Opposite Crank (2210)
11	2210-11	Main Shaft Assembly	45	2210LH-45	Cover Assembly, Opposite Crank (2210LH)
12	2210-12	Bail Wire Assembly (2210)	46	2210-46	Level Wind Yoke (2210)
12	2210LH-12	Bail Wire Assembly (2210LH)	46	2210LH-46	Level Wind Yoke (2210LH)
13	2210-13	Pickup Housing Nut (2210)	47	2210-47	Retainer Clip
13	2210LH-13	Pickup Housing Nut (2210LH)	48	2210-48	Yoke Screw
14	2210-14	Pickup Housing Lock Washer	49	2210-49	Level Wind Roller
15	2210-15	Pickup Housing (2210)	50	2210-50	Drive Gear Assembly (2210)
15	2210LH-15	Pickup Housing (2210LH)	50	2210LH-50	Drive Gear Assembly (2210LH)
16	2210-16	Roller Mounting Bracket Screw	53	2210-53	Non-reverse Pawl (2210)
17	2210-17	Bail Trip Lever Screw	53	2210LH-53	Non-reverse Pawl (2210LH)
18	2210-18	Bail Trip Lever (2210)	54	2210-54	Non-reverse Pawl Spring (2210)
18	2210LH-18	Bail Trip Lever (2210LH)	54	2210LH-54	Non-reverse Pawl Spring (2210LH)
19	2210-19	Bail Trip Lever Spring (2210)	55	2210-55	Non-reverse Cam (2210)
19	2210LH-19	Bail Trip Lever Spring (2210LH)	55	2210LH-55	Non-reverse Cam (2210LH)
22	2210-22	Line Roller	59	2210-59	Cover Assembly, Crank Side (2210)
23	2210-23	Roller Mounting Bracket (2210)	59	2210LH-59	Cover Assembly, Crank Side (2210LH)
23	2210LH-23	Roller Mounting Bracket (2210LH)	60	2210-60	Throwout Lever
24	2210-24	Roller Mounting Bracket Screw	61	2210-61	Throwout Lever Screw
25	2210-25	Bail Torsion Spring (2210)	63	2210-63	Crank Assembly
25	2210LH-25	Bail Torsion Spring (2210LH)	63	2210LH-63	Crank Assembly
27	2210-27	Lock Washer	64	2210-64	Cover Screw, Crank Side
28	2210-28	Roller Lock Nut			
37	2210-37	Pickup Housing Thrust Washer			
39	2210-39	Bearing Retainer Screw (2210)			
39	2210LH-39	Bearing Retainer Screw (2210LH)			