



SOLSTACE 2000RB 97

SO2000RB

Part #	Description	Part #	Description	Part #	Description
RD 0026	Ball Bearing	RD 3471	Anti-Reverse Cam Spring	RD 3752	Key Washer (A)
RD 0041	Drive Gear Washer	RD 3651	Bail Spring Guide (A)	RD 3753	Drag Coil Spring
RD 0050	Anti-Reverse Lever Screw	RD 3652	Bail Spring Guide (B)	RD 3754	Drag Spring Washer
RD 0071	Rotor Nut	RD 3656	Anti-Rverse Ratchet	RD 3755	Pressure Screw
RD 0540	Multi-Purpose Screw	RD 3658	Anti-Reverse Pawl	RD 3756	Drag Knob Spacer
RD 0544	Drag Washer C (Cloth)	RD 3659	Anti-Reverse Pawl Spring	RD 3787	Drag Knob Screw
RD 0642	Side Cover Screw	RD 3660	Anti-Reverse Cam	RD 3869	Anti-Reverse Lockout Spring
RD 0779	Bail Hold Support Screw	RD 3673	Oscillating Gear	RD 4051	Bail Spring
RD 0786	Trigger Screw	RD 3702	Bail Spring Cover	RD 4160	Trigger Cam
RD 0787	Nut Lock Screw	RD 3706	Rotor	RD 4163	Line Roller Bushing
RD 0792	Bearing Retainer Screw	RD 3708	Counterbalance Cover	RD 4364	Quickfire II Trigger
RD 0930	Ball Bearing	RD 3739	Main Shaft	RD 4366	Bail Arm
RD 1008	Handle Lock Washer	RD 3740	Pinion Gear	RD 4367	Line Roller Screw
RD 1890	Bushing Washer	RD 3742	Drive Gear	RD 4370	Bail Assembly
RD 1891	Bail Spring Cover Screw	RD 3743	Hold Click Spring	RD 4421	Handle Screw Cap
RD 2280	Anti-Reverse Lock Out	RD 3744	Drag Click	RD 4454	Handle Assembly
RD 2283	Anti-Reverse Pawl Screw	RD 3745	Oscillating Slider	RD 4553	Line Roller
RD 2852	Handle Screw Lock	RD 3746	Oscillating Slider Retainer	RD 4906	Anti-Reverse Lever
RD 3125	Drag Click Screw	RD 3747	Slider Retainer Screw	RD 4909	Spool Assembly (Aluminum)
RD 3359	Line Roller Washer	RD 3748	Drag Shaft	RD 4920	Side Cover
RD 3402	Cover Screw	RD 3749	Drag Washer C (White)	RD 4922	Drag Knob
RD 3410	Bail Trip Lever	RD 3750	Eared Washer B	RD 4923	Body
RD 3445	Spool Assem. (Graphite)	RD 3751	Drag Washer C (Blue)		