




Please order by parts number, not key number  
Veuillez indiquer le numéro de la pièce (Non "Key" No.)

## CONVENTIONAL REEL **SALTIGA LD20-2SPEED/LD30-2SPEED**



Key No.	Parts No.	Parts Name
1	E66-4501	Frame
2	E63-9601	Click plate
3	E65-6501	Click spring (A)
4	E63-9501	Click button
5	E61-7302	Click button washer
6	E66-4701	Click pawl
7	E67-1301	Washer (A)
8	E66-4801	Click spring (B)
9	320-1402	Click pawl retainer
10	E67-1401	Ring holder
11	E67-1501	Screw (A)
12	E67-0001	Frame plate
13	351-7701	Screw (B)
14	E66-4901	Spool
15	G53-6001	Ball bearing (A)
16	E57-8301	Washer (B)
17	E64-1201	Drag spring washer
18	E66-5101	Main shaft
19	E64-1601	Drive shaft pin (A)
20	E66-8801	Drag click cap
21	E64-1501	Screw (C)
22	B35-2701	Brake collar
23	E66-5001	Drag washer
24	G49-8505	Ball bearing (B)
25	E64-1301	Spring (A)
26	G49-8505	Ball bearing (C)
27	E66-5601	Drag plate
28	E66-6001	Cover
29	E66-8901	Screw (D)
30	E66-5801	Packing
31	E64-3401	Drag ratchet
32	E66-6801	Pinion gear (A)
33	E64-2801	Pinion gear (B)
34	E66-9101	Washer (C)
35	E17-5802	Ball bearing (D)
36	E66-6101	Right side plate
37	E64-3501	Drag pawl
38	E64-3701	Drag pawl retainer
39	E64-3801	Screw (E)
40	E66-6201	Drive shaft
41	E64-1901	Drive shaft pin (B)
42	G47-2501	Ball bearing (E)
43	E66-9001	Washer (D)
44	E64-2201	Drive gear collar (A)
45	E64-2301	Drive gear (A)
46	E64-2401	Drive gear collar (B)
47	E64-2501	Drive gear (B)
48	E65-6801	Drive gear collar (C)
49	E64-2601	Drive gear collar (D)

Key No.	Parts No.	Parts Name
50	E64-2701	Drive shaft nut
51	E66-6301	Drive shaft spring (A)
52	E66-6401	Drive shaft screw
53	E66-6501	Drive shaft pin (C)
54	E64-4301	Collar (A)
55	E59-1601	Screw (F)
56	E66-6901	'O' ring (A)
57	E64-4101	Washer (E)
58	E64-3901	Spring (B)
59	E64-4001	Pin (A)
60	E65-9901	Pin (B)
61	E64-5001	Drag lever plate (A)
62	E64-1501	Screw (G)
63	E66-0901	Drag lever plate (B)
64	E66-7001	Drag lever
65	E66-7401	Pre-set cam (A)
66	E66-7501	Ring (A)
67	E66-7601	Pre-set cam (B)
68	171-1001	O' ring (B)
69	E64-5801	Drag knob spring
70	E66-7901	Click leaf spring
71	E66-7801	Pre-set drag knob
72	E64-4501	Screw (H)
73	G21-1701	Pin (B)
74	E66-6701	Drive shaft spring (B)
75	E66-6601	Collar (B)
76	G52-2801	Ball bearing (F)
77	E66-8101	Collar (C)
78-85	E66-8201	Handle assembly
86	E64-7301	Handle screw (A)
87	320-5901	Retainer
88	E66-8501	Handle button
89	E66-8601	Handle cap (A)
90	E66-9301	Screw (I)
91	E64-7801	Plate
92	E64-7701	Spring (C)
93	E64-7901	Handle lever
94	H56-2101	Handle cap (B)
95	E49-2101	Handle screw (B)
96	H60-0701	Clamp screw
97	H60-0601	Rod clamp
98	H60-0801	Clamp bolt

### Special Parts for SALTIGA LD30-2SPEED

Key No.	Parts No.	Parts Name
1	E66-9501	Frame
14	E66-9701	Spool
18	E66-9801	Main shaft
36	E66-6102	Right side plate