



CSD-12S PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001693	MAIN BODY ASSY	702	17020272	PINION GEAR ASSY
102	11020030	BODY FOOT	720	17200003	DRIVE GEAR SHAFT BUSHING
114	11140037	CAMP	726	17260006	DRIVE GEAR BUSHING
115	11150003	WUNG SCREW	800	18000023	CLUTCH SHAFT
116	11160012	WING NUT	801	18010007	CLUTCH SPRING
116-1	11160013	WING NUT	802	18020120	CLUTCH BAR ASSY.
117	11170011	RETAINER NUT	804	18040008	CLUTCH SLIDER
117-1	11170002	RETAINER NUT	805	18050004	PINION GEAR YOKE
120	21200002	MAIN BODY PIN	806	18060001	YOKE SPRING
200	12001890	HANDLE SIDE PLATE ASSY	815	18150005	CLUTCH BAR SCREW
201	12010037	ANTI-RE PAWL	901	19010001	C RETAINER
202	12020019	RATCH	900	29000002	E RETAINER
207	12070094	HOLDED PLATE	910	0910098	BALL BEARING
211	12110016	ANTI-RE PAWL PIN	910	0910153	BALL BEARING
215	12150013	HOLD PLATE BUSHING	910	0910012	BALL BEARING
216	12160006	ANTI-RE PAWL SPRING	910	0910029	BALL BEARING
300	13001024	VICE SIDE PLATE	920	0920435	WASHER
302	13020015	BUSHING	920	0920114	WASHER
302-3	13020030	WASHER	920	0920162	WASHER
303	13030074	CLICK BUTTON	920	0920448	WASHER
304	13040023	CLICK PAWL	920	0920081	WASHER
305	13050009	CLICK PAWL SPRING	920	0920310	WASHER
400	14000879	SPOOL ASSY.	920	0920133	WASHER
401	14010030	CLICK GEAR	920	0920486	WASHER
500	15000343	HANDLE ARM ASSY.	920	0920458	WASHER
515	15150002	HANDLE SCREW	930	09301182	SCREW
600	16000106	CAST CONTROL CAP	930	09301183	SCREW
609	16090009	DRAG SPRING WASHER	930	0930988	SCREW
610	16100051	DRAG WASHER	930	0930196	SCREW
612	16120073	KEY WASHER	930	0930431	SCREW
612-1	16120035	KEY WASHER	930	0930202	SCREW
614	16140003	DRAG WASHER	930	0930176	SCREW
615	16150186	STAR DARG ASSY	930	0930525	SCREW
618	16180002	WASHER	930	0930152	SCREW
700	17000324	DRIVE GEAR ASSY	940	0940032	O RING
701	17010154	DRIVE GEAR SHAFT ASSY.			