NO.		PART NO.	NAME OF PART
36		27320	WASHER
37		33165	ANTI-REVERSE CLAW
38		27295	WASHER
39		28435	ANTI-REVERSE LEVER SPRING
40		14130	ANTI-REVERSE CAM
41		19267	HANDLE RETAINING SCREW
42		27310	RETAINING WASHER
43		20098	SCREW
44		27205	RETAINING WASHER
45		15269A	ANTI-REVERSE LEVER
46		03153	MAIN BODY ASSEMBLY
47		38029	OILLESS BUSH
48		08116A	MAIN GEAR
49		11079	OSCILLATING SLIDER ARM
50		23163	OSCILLATING SLIDER PIN
51		27079	WASHER
52		04195	SIDE PLATE
53		19269	SCREW
54		07186	HANDLE ASSEMBLY